

Southern PIKNIK®

Permanent Bench Assembly



1. Attach backrest section to the “hat section” backrest support stanchions as shown on sketch below. The 1/4” flat bar riveted to inside of top return flange secures the top of the backrest stanchion to the backrest.
2. Install the backrest assembly to the bench seat section with the bolt clip system reinstated to the backrest support stanchions. The clips engage the return flanges on bottom of seat section.
3. Bolt the 4” channel vertical main supports to the angle brackets which are riveted to the return flanges of the bottom of seat section.
4. Set the channel support in concrete with the bottom surface of the seat section 15” above ground. Plumb the channel supports.

